

索引

ラ

*ラベル 6-6

A

ABS 6-6
ACCEL 6-6
ADR 6-9
ALT 6-10
AR\$ 6-10
ASC 6-11
ATAN 6-11
ATAN2 6-11

B

B_OUT 6-11
BSY 6-11

C

CASE 6-12
CASE_ELSE 6-12
CEL 6-12
CHR\$ 6-12
CLK 6-12
CLP 6-13
CLRPOS 6-13
CMND 6-13
CNFG#0 6-13
CNFG#2 6-14
CNT 6-14
COMSET 6-14
CONST 6-14
CONT 6-14
COS 6-15
CP 6-16
CURPOS 6-16

D

DATE 6-16
date\$ 6-16
DEL 6-17
DELETE 6-17
DIM 6-17
DIM_AR\$ 6-17
DIR 6-17
DO.. LOOP 6-18
DS_CLK 6-18
DS_PG 6-18
DSC 6-18
DUMP 6-19

E

EIF 6-19
ELSE 6-19
EN_CLK 6-19
EN_PG 6-19
ENC 6-19
END 6-19
END_IF 6-19
END_SELECT 6-19
ERA 6-19
ERASE 6-19
ESL 6-19

F

FAST 6-20
FEDD 6-20
FEDH 6-20
FEDT 6-20
FEDZ 6-21
FEED 6-21
FIND 6-21
FIX 6-22
FOR.. NEXT 6-22
FORK 6-22
FREE 6-23

G

GO 6-23
GOSUB 6-23
GOTO 6-23

H

HEX\$ 6-23
HIN 6-24
HOME 6-24
HOMZ 6-25
HOUT 6-25
HPT 6-25
HSW 6-26

I

IF 6-26
IN 6-26
INP\$#0 6-27
INP\$#2 6-27
INPBLK# 6-27
INPUT 6-27
INPUT\$ 6-32
INPUT#0 6-33
INPUT#2 6-33

INT1 6-33
INT2 6-33
IO 6-33
IOR 6-33
IOW 6-34

J

JMPZ 6-34
JUMP 6-34

L

LEN 6-34
LET 6-35
LIMZ 6-35
LINK 6-36
LIST 6-36
LOF 6-36
LOOP 6-37
LP 6-37

M

MBK 6-37
MEM 6-37
MON 6-37
MONIT 6-38
MOVE 6-38
MOVZ 6-38
MPC 6-38
MPCINIT 6-39
MULTI 6-39

N

NEW 6-39
NEWP 6-39
NEXT 6-39
NOT 6-39

O

OFF 6-40
ON 6-40
OUT 6-40

P

P 6-40
P_HSW 6-41
P_IN 6-41
P_LD 6-41
P_OFF 6-41
P_ON 6-41
P_OUT 6-41
P_SV 6-42

P_SW	6-42
PALET1	6-43
PALET2	6-44
PALET3	6-44
PALET4	6-44
PAUSE	6-44
PEEK	6-44
PG	6-44
PGSEL	6-46
PL1	6-47
PL2	6-47
PL3	6-47
PL4	6-47
PLIST	6-47
PLS	6-47
POKE	6-48
PR	6-48
PRINT	6-48
PRINT#0	6-49
PRINT#2	6-49
PRX	6-49
PULSE	6-49
PUT	6-50
PUT#0	6-50
PUT#2	6-50

Q

Q_PAUSE	6-51
QUIT	6-53

R

RAM	6-54
RANGE	6-54
RD	6-55
REG	6-55
REG3	6-56
RENUM	6-56
RET	6-56
RETURN	6-56
RLS	6-56
RM	6-56
RMOV	6-57
RMVZ	6-57
RNM	6-56
ROM	6-57
RS	6-57
RSE	6-57
RSV	6-58
RUN	6-59

S

S_MBK	6-59
SELECT_CASE	6-59
SENSE_SW	6-60

SET	6-60
SETIO	6-61
SETP	6-61
SETPOS	6-61
SETX	6-62
SFTL	6-62
SFTR	6-63
SHMZ	6-63
SHOM	6-63
SIN	6-63
SINGLE	6-63
SLC	6-59
SLOW	6-63
SP	6-64
SQ	6-64
SQR	6-64
ST	6-64
ST_REG	6-64
STOP	6-65
STR\$	6-68
STRCPY	6-68
SW	6-69
SWAP	6-69
SWP	6-70
SYSCLK	6-70

T

TAIL	6-70
TAN	6-70
TASK	6-71
TASKN	6-71
TD	6-71
TEACH	6-72
TEST	6-72
TIME	6-72
time\$	6-73
timer	6-73
TMON	6-73
TMOUT	6-73
TOFF	6-73
TON	6-73
TR	6-74

U

U	6-76
UNTIL	6-76
USERCOM1~9	6-77

V

VAL	6-77
VER	6-77
VLIST	6-77

W

WAIT	6-78
WEND	6-78
WHILE	6-78
WIR	6-78
WOW	6-78
WS0	6-79
WS1	6-79

X

X	6-80
---	------

Y

Y	6-80
---	------

Z

Z	6-80
---	------

MPC - 684ユーザーズマニュアル

2000年9月 改訂第5版
発行責任者 横田 隆一
発行所 株式会社アクセル
〒391-0005
長野県茅野市仲町 16-32 トウブビル5 F
TEL 0266(72)8465 FAX 0266(72)8436
E-mail webmaster@accelmpc.com
<http://accelmpc.com>
企画・編集 フリーシステム

この印刷物は古紙100%の再生紙を使用しています。